Subject: Re: Technics SL1500 problem - down a channel or ?
Posted by Wayne Parham on Tue, 04 Sep 2007 13:48:26 GMT
View Forum Message <> Reply to Message

Well, one thing is for sure. If the center pin of the right channel's RCA connector isn't conductive, then you'll have no right channel output. Could be that the turntable was used for mono, I suppose.