Subject: Re: turntables
Posted by Bill Epstein on Sat, 15 Dec 2007 20:34:28 GMT
View Forum Message <> Reply to Message

I'd first check the 2 cartridge grounds, then switch carts, finally pop the bottom cover and check the ground connection to the arm cabkle circuit board for a good connection and continuity to the cartridge pins.