

---

Subject: Re: turntables

Posted by [Bill Epstein](#) on Sat, 15 Dec 2007 20:34:28 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'd first check the 2 cartridge grounds, then switch carts, finally pop the bottom cover and check the ground connection to the arm cable circuit board for a good connection and continuity to the cartridge pins.

---