
Subject: JVC L-A11 anti-skating
Posted by [mikesloane](#) on Mon, 07 Jul 2008 00:53:06 GMT
[View Forum Message](#) <> [Reply to Message](#)

I was given the above turntable, and it seems to work fine, but I don't know how to adjust the anti-skating knob. Since I didn't get a manual with the unit, I wonder if anyone can give me some guidance.
