

---

Subject: Re: JVC L-A11 anti-skating

Posted by [Wayne Parham](#) on Thu, 17 Jul 2008 17:03:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Usually anti-skating is set the same as the tracking weight, but not always. The simple no-guage eyeball method is to look at the stylus as it tracks a record and set the anti-skate where the needle is centered, i.e. not deflected left or right. Check through the posts on setup for more information.

---