

---

Subject: Trio/Kenwood KD 550

Posted by [Catherine](#) on Tue, 26 Aug 2008 13:55:30 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi,I'm thinking of buying one of these decks and I can't work out whether or not it's got a start stop button, i.e. so I can cue up a track and leave the needle on the record. The person selling it said they don't think it does, that it just has the hydraulic lever to move the arm up and down but I thought that most direct drive decks would have the start button to cut the power from the motor.thanks!

---