

---

Subject: Re: How can I adjust the tone arm so it does not miss the edge of the record?

Posted by [Wayne Parham](#) on Tue, 31 Mar 2009 17:33:36 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Talking about the screw at the base of the tone arm, are you sure that's not anti-skate? If it's an anti-skate adjustment, that's not what you want to change for needle auto setdown and/or pickup position. Tracking weight and anti-skate should be set as shown in the links below. Auto pickup and setdown is another adjustment, usually located inside the body somewhere. Turntable tone arm and cartridge setup

---