Subject: Re: How can I adjust the tone arm so it does not miss the edge of the record?
Posted by Wayne Parham on Wed, 08 Apr 2009 17:27:56 GMT
View Forum Message <> Reply to Message

I'd look at the mechanism to identify the stops. There has to be something that senses the edges of the record, both inner and outer, a sensor or switch that contacts a cam or stop.You might be best off to contact Gararrd501.com and ask those folks. Please report back when you do, as we're all interested in the solution you eventually find.