

---

Subject: Re: How can I adjust the tone arm so it does not miss the edge of the record?

Posted by [Wayne Parham](#) on Wed, 08 Apr 2009 17:27:56 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'd look at the mechanism to identify the stops. There has to be something that senses the edges of the record, both inner and outer, a sensor or switch that contacts a cam or stop. You might be best off to contact [Gararrd501.com](#) and ask those folks. Please report back when you do, as we're all interested in the solution you eventually find.

---