

---

Subject: Re: How can I adjust the tone arm so it does not miss the edge of the record?

Posted by [david](#) on Wed, 08 Apr 2009 17:58:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It's like you're speaking a foreign language. I don't know a stop from a cam or a sensor, and I don't see any mention of these things in the 440M manual. I will try [Garrard501.com](#). Didn't know there was such a place. Thanks.

---