

---

Subject: Solenoid part availability for "PLAY" for SS700 Crown Reel Player

Posted by [Terry P.](#) on Mon, 13 Feb 2006 12:07:14 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thank you for your suggestion. All I am knowledgeable of is that the tech who last tried to repair the unit said it needed a new solenoid. No mention was made of a rebuild, and I don't know what I'm looking at or for, to check the coil. Obviously, nothing happens (no click) when the play button is pressed. All other buttons give an audible click as they engage.

---