

---

Subject: Re: Sony TC-650 reel deck brakes  
Posted by [slbender](#) on Tue, 06 Mar 2007 20:41:25 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Hi,I have most parts for the TC-650 ( one got destroyed in shipping on its way to me from Florida. The brake pads are probably worn, or the spring tensioner needs to be set at a higher level. These things can be checked by taking the front panel off and operating the set.-Steven L. Bender

---