
Subject: Re: CAL Icon CD player
Posted by [Mike Gibson](#) on Sun, 22 Mar 2009 08:27:14 GMT
[View Forum Message](#) <> [Reply to Message](#)

I'd take the cover off and look to see if the drawer is belt driven. I've fixed several old Denons by using a 1/16" O-Ring because I didn't have the correct belt and they're still opening and closing.
