
Subject: Re: Adjusting for difference in gain in biamping
Posted by [Wayne Parham](#) on Mon, 09 Feb 2004 20:11:36 GMT
[View Forum Message](#) <> [Reply to Message](#)

Use a trim pot to set the input level of the louder amp. Install it exactly as you would a volume control potentiometer.
