Subject: Re: split impedance
Posted by Bill Martinelli on Sun, 05 Sep 2004 15:42:13 GMT
View Forum Message <> Reply to Message

Please explain how the amplifier can see or sense individual components past the passive crossover? I always thought the amp would only see the total load and impeadance that is given at the point of entry, the crossover.