

---

Subject: Re: Crackling

Posted by [Wayne Parham](#) on Sun, 08 Apr 2007 15:21:58 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Sounds like the voice coil is rubbing, but it could be the output amp instead. Try the speakers on a different amp or the amp on different speakers and see if you can isolate which is causing the problem.

---