Subject: Speaker/Amp connections
Posted by Wayne Parham on Sun, 16 Dec 2007 16:00:43 GMT
View Forum Message <> Reply to Message

channel output and the right speaker connected to the amplifier's right channel output. Each speaker's (+) terminal is connected to the (+) terminal on the amp and the (-) terminal on the speaker is connected to the (-) terminal on the amp. If that's how you have it connected, you've done everything right.