
Subject: Speaker Wire/Setup/Receiver Question
Posted by [Zac P](#) on Tue, 12 Aug 2008 16:39:36 GMT
[View Forum Message](#) <> [Reply to Message](#)

In my house I have 2 speakers upstairs and one down. The three speakers are fairly large. I have a problem when i turn my receiver close to max it throws it into protect because I think I am getting current back into the receiver somehow (Maybe because of the length of the wire). I am using 10 gauge wire and i was wondering if I should lower the gauge or if there is something else up.Thanks!
