

---

Subject: Re: Yet Another HORNRESP Question....  
Posted by [Wayne Parham](#) on Fri, 02 Apr 2004 14:55:40 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

That's net. You must enter the actual throat chamber volume. This is usually the volume between the cone and the mounting plate for cone-driven horns. Also include the volume made from the cross-section area of the mounting plate and its thickness, although most times this is small enough it doesn't matter much.

---