

---

Subject: What does the bottom end do?

Posted by [spkrman57](#) on Thu, 02 Mar 2006 13:10:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Well, for one it makes your upper frequencies sound better also as there is treble info in the bass, and there is bass detail info in the upper freq's also. Also Thatch-ear, the bottom end of the D123 in standard reflex would be approx 45hz and drops like a rock after that. There is deeper bass available, but it is about 20db less the efficiency of the D123 as a whole. Ron

---