Subject: Floor bounce
Posted by Geoserv on Mon, 14 May 2007 17:12:44 GMT
View Forum Message <> Reply to Message

What do you do to prevent the notch from floor bounce? If a single driver is used, do you place it low to the ground to prevent floor bounce or place it high on the baffle near ear level and just live with a notch in response from floor bounce?