Subject: Sony DVP-S9000ES Video Off problem
Posted by David Stone on Mon, 16 Feb 2004 22:12:38 GMT
View Forum Message <> Reply to Message

Have the mentioned SACCD/DVD player. Somehow, the Video Off button has been activated so we cannot see a DVD image, although sound is fine.The "video off" light is on. Re-pressing the Video on/off button does nothing ! Nothing mentioned in the poorly written manual at all. This happended once before a I recall some sort of off-the-wall solution but cannot recall it, not can I find where I wrote it down.Can anyone help? Sony's help line never answers ..... TIA.