Subject: Loose cap on top of tubes Posted by John White on Wed, 15 Sep 2004 19:28:14 GMT View Forum Message <> Reply to Message

Hi all, nice site!I just bought a great little tube radio and it works good too! The thing is there are two tubes inside with connectors on top that seem loose. There is a wire attached and it's pretty snug. I'm concerned because the little cap on top is loose. You can rotate it back and forth a little bit. The tubes work, or at least the radio does, but I think it is odd that these caps are loose. Is that normal? Do I need new tubes?Thanks in advance,John White

Page 1 of 1 ---- Generated from AudioRoundTable.com