

---

Subject: Re: Lenco 35

Posted by [Manualblock](#) on Mon, 20 Dec 2004 21:01:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Wait a minute; excuse my ignorance, I read through your post so quickly that what you said escaped me. You claim that you turned the volume nob to zero? I assumed you said the start control to zero. What exactly does the volume nob control? Is this a console set? Thank you J.R.

---