

---

Subject: Re: h!!h studio 50

Posted by [hitsware](#) on Tue, 21 Dec 2004 15:23:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It may if not drawing enough current to pull down the supply. Best to disconnect your speaker or you may burn it up !!!!!

---