

---

Subject: Cinemode, Progressive and Interlaced. What's the difference?

Posted by [Neutron](#) on Sun, 05 Sep 2004 19:58:55 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I have 3 picture modes that I do not understand. I know what progressive and interlaced means but I don't know what cinemode is. Besides, changing between them doesn't seem to make any difference. What do I use them for? Why doesn't the television automatically adjust itself for the best/right mode?

---