

---

Subject: Re: 5V CT rectifier hookup - help  
Posted by [cheetah](#) on Fri, 25 Feb 2005 19:18:32 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

For rectifier heaters, the center tap is connected to the LC power supply filter. The ends of the transformer connect to the filament pins. Joe

---