
Subject: Re: 5V CT rectifier hookup - help
Posted by [cheetah](#) on Fri, 25 Feb 2005 19:18:32 GMT
[View Forum Message](#) <> [Reply to Message](#)

For rectifier heaters, the center tap is connected to the LC power supply filter. The ends of the transformer connect to the filament pins. Joe
