

---

Subject: Re: Adjusting R3

Posted by [PakProtector](#) on Sat, 26 Feb 2005 23:08:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hey-Hey!!!For this you ignore the mu output. Put the ammeter or sensing resistor in series with a 9V battery. + to the upper drain and - to the plate end of R-3. Watch the meter and adjust until the CCS is passing the 15 mA of current. If you use a sense resistor, use Ohm's Law to determine current. If you use the mA function then you'll get the reading directly. It will probably come in when R-3 is ~150R or so. Call if you wish, I will talk you through it.regards,Douglas

---