Subject: Rectifier heater voltage Posted by colinhester on Wed, 09 Mar 2005 18:23:16 GMT View Forum Message <> Reply to Message

Well, I used the 6V4 with the 5V tap. Turns out the 6V4 should be run off 6.3V. It works well with the 5V but I will up the voltage. Thanks for pointing this out. I should have paid more attention.....Colin http://tdsl.duncanamps.com/show.php?des=6V4