
Subject: What? You don't get 300 watts from your amp?
Posted by [Forty2wo](#) on Wed, 31 May 2006 03:07:08 GMT

[View Forum Message](#) <> [Reply to Message](#)

What, read the x1 scale, rather than the x10 scale? I would never admit to a dumb mistake like that. Well, OK. More like 20V p-p or 7-8V rms, for more like about 4 watts. The test setup, such as it was... Readings taken from the transformer output (a Lundahl 1623, Connected as 5.6k -16 ohms). Into a 16 ohm non inductive dummy load. I use this setup so I can connect to friends, 8 ohm speakers. So, after you so kindly pointed out the gross errors. I see that I need a bit more voltage swing on the driver. I will work on raising V_a next. Thanks for your dB refresher course, I guess it's "use it or lose it" Or what was the question again ? ...John
