
Subject: piezo buzzing when amp clips.

Posted by [Andy G](#) on Thu, 24 Jan 2002 00:27:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

The piezo is protected? by (from the piezo) an 18ohm in series, then 22ohms parallel then 2 μ F in series. This should give some cut below 3500. When the amp clips, the piezo really buzzes, is there any way I can stop this happening??
