

---

Subject: Speaker motor models in Spice

Posted by [Wayne Parham](#) on Wed, 27 Feb 2002 17:27:42 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The values  $R_e$  and  $L_e$  are taken directly from manufacturer's specifications. The mechanical reactance values are those that are equivalent to the driver's mechanical  $Q$ .