

---

Subject: My question re boomy subs

Posted by [Paul C.](#) on Fri, 17 May 2002 20:08:41 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

One thing I want to ask designers of some car audio (and many home stereo) subs... why, when I perform music, the bass line has different notes in it, but when your subs play the same music, all the bass notes have the same indeterminant pitch? And I have NEVER heard a drummer's kick drum that sounded like THAT! Drummers go to great lengths to damp their kick drum, for a quick Whap! But your "4th order sub" goes "wooooooooooom, wooooooooooooom, da wooooooooooooom". Why is that? Which "wooooooooooms" are the electric bass, and which are the kick drum?

---