

---

Subject: Re: Tolerance

Posted by [Erik Johansson](#) on Mon, 15 Jul 2002 15:04:14 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Here is a picture of the ports I will be using. As you can see it's outer edge will extend about 2.5mm from the baffle (if I don't recess it which I don't have the tools to do) due to the flange with the screw holes. From where do I measure the length of the port? From where it starts (2.5mm out from the front baffle) or from the outside of the baffle?/Erik

---