Subject: Three-way systems
Posted by Wayne Parham on Fri, 25 Oct 2002 19:01:02 GMT
View Forum Message <> Reply to Message

The crossover can be configured for first or second order LF and MF sections and a third-order

the crossover is configured for first-order LF and MF slopes.