

---

Subject: JBL 2426

Posted by [bqc](#) on Tue, 26 Nov 2002 23:11:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I just bought a couple of these. The spec says that the top plate where the horn is bolted to can be removed so that a 1 3/8 18 TPI type horn lens can be thread onto the 2426. Does anyone know how to remove the top plate? Do I just turn it counter clockwise real hard till it moves or do I need to unscrew 3 screws that are located on the bottom of the driver, where the binding post are located. Thanks

---