

---

Subject: Re: Hornresp MMD spec  
Posted by [Smrtislav](#) on Thu, 27 Mar 2003 17:23:22 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Hi, in almost every window in the driver parameters section pressing pops up a window, where you put T/S parameters in and the program computes the value. Or it is in the menu under Tools-Convert parameter.K.

---