
Subject: Re: Top-octave compensation

Posted by [DRC](#) on Fri, 02 May 2003 14:07:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Wayne! If I vary the value in the cap you supplied in the compensation network (.47uf), I assume I'm moving the point where the compensation starts. Where does it kick in at this value, and where would it happen at .33uf? (Alternatively, where can I look to answer these silly questions myself?) (Feed a man a fish and he's set for one day, teach him to fish) ;-)

Keep your ears and your mind open.
