

---

Subject: Re: upward axis shift

Posted by [Wayne Parham](#) on Wed, 14 May 2003 18:06:13 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The tweeter driver is shifted back because of the horn, but isn't really that much further back than the woofer. As you said, woofer inductance makes a delay too. The amounts of each are set by the properties of the drivers themselves.

---