

---

Subject: Re: PiAlign program

Posted by [David Morrison](#) on Wed, 21 Jan 2004 19:57:51 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I understand the i enter the parameters and get the recomend box and tuning. I pick a port but do i match both a Q and Fre to the recomend box. better put how do you know what port to use my other boxes are based on cone area, EBP, and Xmax. Also is it possible to change the box volume for the motor cabinet. with the RF2210 i want to use 1 cu ft. also does the box volume include port and speaker. with a 9512 the sub is twice the box volume.

---