Subject: Attenuator/Compensator Posted by dlawter on Tue, 09 Mar 2004 22:31:23 GMT View Forum Message <> Reply to Message

In looking over your crossover document I'm a little confused by your choice of parts for the attenuator. Your diagram shows R1=16 and R2=25 ohms for 12db attenuation but for an 8 ohm crossover I would use 6 ohms and 2.68 ohms instead. I would also reverse the order of them, putting the parallel resistor closest to the tweeter. It looks like what you have will load the crossover improperly like having a 16 ohm driver on an 8 ohm crossover. What gives?

Page 1 of 1 ---- Generated from AudioRoundTable.com