

---

Subject: pi align software

Posted by [Adam Wilson](#) on Sat, 26 Feb 2005 17:55:15 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Wayne, In the Pi align software does bandwidth refer to the entire frequency range of the bare driver or simply to the range between the low and high cutoffs you are designing for? Thanks for your great products ( I am the proud owner of your Theater 4s) and generous sharing of your knowledge. Adam Wilson

---