

---

Subject: Re: pi align software

Posted by [Wayne Parham](#) on Sat, 26 Feb 2005 18:09:50 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I assume you are referring to the "Lo Cut" and "Hi Cut" fields. Those were originally intended to store raw driver cutoff points, though I rarely used them. When I started writing that software, I had intended to use it to do the electro-mechanical alignment, catalog driver specs and assist in designing the crossover. The source code has another screen and various modules that were never completed. I decided to remove the menu control to take you to the crossover screen. When I use the program as it stands, rarely do I ever enter values for midrange and tweeter components, or even the values for woofers beyond quantity, Vad, Qd and Fd.

---