

---

Subject: Re: Active Crossover

Posted by [Wayne Parham](#) on Mon, 16 May 2005 01:18:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Set it between 1.2kHz and 1.6kHz, no lower for the PSD2002. You want to be able to set the LF and HF points independently, if possible. Also, you'll want to be sure to use tweeter compensation or it will not sound good.

---