

---

Subject: Active xover's

Posted by [GrantMarshall](#) on Thu, 28 Jul 2005 10:13:55 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

With active xover's you have to pay attention to ohm's of the driver. With actives you don't. I'm assuming they automatically correct somehow or are they set for 8 ohm and aren't true for other impedences? Thanks in advance. Grant.

---