

---

Subject: Re: Four Stage

Posted by [Wayne Parham](#) on Tue, 06 Sep 2005 21:58:50 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

In the three-way speakers, the tweeter is always on top. In the two-way speakers, if you move it to the top, as some have done, you should shift the midwoofer upward in the box to keep the distance between the two the same as if they were in the box.

---