
Subject: Re: What about those flashing lights????
Posted by [Chris R](#) on Wed, 14 Sep 2005 23:51:46 GMT
[View Forum Message](#) <> [Reply to Message](#)

I'll re-check a few things when I get home. For a 10dB, 8 ohm driverpad, what are the series and parallel resistor values supposed to be? I may have those wrong (too big). That wouldn't explain the blinky lights, but I'm a little worried I whacked the X-over freq.thx, Chris
