
Subject: Re: Le (T/S)
Posted by [dB](#) on Sat, 18 Feb 2006 17:23:44 GMT
[View Forum Message](#) <> [Reply to Message](#)

Thanks Wayne, Just the voice coil L. Is it the same published as Le (like in the one Le for the Eminence drivers. Is it L (or Le, inductance) measured at 1KHz? Other brands as beyma and Selenium, just write the frequency in front of Le as; Le@1KHz, Le@Fs, Le@20KHz.
