

---

Subject: Re: Compensation circuit when using active crossover  
Posted by [Wayne Parham](#) on Mon, 27 Mar 2006 21:51:11 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

The series resistor will be dependant on load impedance. Bypass cap is found using the up and down doubling or halving values 'till you get where you want to be.

---